

Hazardous Cupboard Specification Sheet



Sizes Available:

<u>Height</u>	<u>Width</u>	<u>Depth</u>	<u>Shelves Supplied</u>	<u>Sump Capacity</u>
1800mm	900mm	460mm	3	14 Litres
1800mm	1200mm	460mm	3	18 Litres
1200mm	900mm	460mm	2	14 Litres
900mm	460mm	460mm	1	7 Litres
900mm	900mm	460mm	1	14 Litres
700mm	350mm	300mm	1	3 Litres
700mm	900mm	460mm	1	14 Litres
(Mobile Cupboard) 1040mm	900mm	460mm	1	-
(Mobile Cupboard) 840mm	900mm	460mm	1	-
(Floor Chests) 610mm	1170mm	460mm	-	20 Litres
(Floor Chests) 510mm	610mm	340mm	-	7 Litres
(Wall Mounted) 570mm	850mm	255mm	1	No Sump Fitted

QMP LTD, Timmis Road, Lye, Stourbridge, West Midlands, DY9 7BQ

Tel: 01384 899800

Fax: 01384 899801

Email: sales@qmp.uk.com

Website: www.qmp.uk.com

Cupboard Construction:

- 0.7mm mild steel, pop riveted carcass construction
- Rust resisting galvanised shelves
- Integral liquid-tight sump fitted at the bottom of the cupboard
- Door aperture has return bends to eliminate open gaps
- Delivered assembled
- Reaction to Fire Classification EN 13501-1 – documents available
- Supplied with one warning label
- 2-point locking mechanism
- Extra Shelves & stands are available with the Hazardous Cupboard range

Sump Construction:

- Material: 1.2mm Mild Steel
- Fully welded seams
- Sump Integral

Cupboard Door Construction:

Material: 0.9mm Mild Steel. A stiffener is spot welded vertically in the centre of the door with two 2.½” butt hinges spot welded to the door. The door is attached to the carcass via the hinges, with 4.8mm pop rivets. The door has two-point locking with an all metal key locking handle.

Paint Finish:

- Three stage pre-treatment and phosphate coating
- Carcass and doors powder coated with one coat Epoxy Polyester Full gloss powder, stoved at 180 deg. C. including Germ Guard antibacterial compound
- Carcass powder coated with a special paint – **Truflow Yellow**

Carcass & Door colour:

High Vis Yellow	Truflow Yellow (Special)
-----------------	--------------------------

QMP LTD, Timmis Road, Lye, Stourbridge, West Midlands, DY9 7BQ

Tel: 01384 899800

Fax: 01384 899801

Email: sales@qmp.uk.com

Website: www.qmp.uk.com

Hazardous Cupboard Floor Chest Specification Sheet



Sizes Available:

<u>Height</u>	<u>Width</u>	<u>Depth</u>	<u>Shelves Supplied</u>	<u>Sump Capacity</u>
(Floor Chests) 610mm	1170mm	460mm	-	20 Litres
(Floor Chests) 510mm	610mm	340mm	-	7 Litres

Floor Chest Construction:

- Material: 1.5mm Mild Steel
- Fully Welded with integrated Sump

Floor Chest Lid Construction:

- Material: 1.5mm Mild Steel
- Fully welded construction with 2 no. welded 2.5" butt hinges.
- Connected to carcass with 4.8mm pop rivets.
- Fitted with restraint to prevent lid from falling back.
- Supplied with Hasp and Staple (Lock not supplied)

Equipment Cleaning & Maintenance instructions:

- Clean paint work periodically with warm soapy water
- Oil hinges and lock sparingly as required with a light oil (3in1 or similar)

QMP LTD, Timmis Road, Lye, Stourbridge, West Midlands, DY9 7BQ

Tel: 01384 899800

Fax: 01384 899801

Email: sales@qmp.uk.com

Website: www.qmp.uk.com



Spares and consumables details inc. sources:

- Replacement locks available from:- QMP LTD or Please contact your supplier
- Spare keys available from: FAST KEY SERVICE LTD, 3, PILOT CLOSE, FULMAR WAY, WICKFORD, SS11 8YW, TEL: 01268 5625862, WEBSITE: WWW.FASTKEYS.CO.UK

QMP LTD, Timmis Road, Lye, Stourbridge, West Midlands, DY9 7BQ

Tel: 01384 899800

Fax: 01384 899801

Email: sales@qmp.uk.com

Website: www.qmp.uk.com